

Item No	Parts No	Title	Description
1	N002.14	Crankshaft + roller cage N002.14	Crankshaft + roller cage
2	15164.81	Roller cage 16x20x23 15164.81	Roller cage 16x20x23
3	57608.02	Piston F1 d.66 complete 57608.02	Piston F1 d.66 complete
4	E001.00	Cylinder+complete piston+gaskets sets VRFE E001.00	Cylinder+complete piston+gaskets sets VRFE
5	ANEL16	Ring for 16 mm wire 1.2 ANEL16	Ring for 16 mm wire 1.2
6	57605.16	Series 2 piston rings 66x1,2 GI chromed rect. 57605.16	Series 2 piston rings 66x1,2 GI chromed rect.
7	57605.33/020	Gaskets Base Skipper thk. 0,20 Flexoid 57605.33/020	Gaskets Base Skipper thk. 0,20 Flexoid
8	N003.22	Gaskets Base Skipper thk. 0,20 Flexoid 57605.33/020	Magnet frame -(Stator)
9	PRI08150.98	Tie-rod cylinder head PRI08150.98	Tie-rod cylinder head
10	7276.38	O.R. d. 72,76x1,78 Viton 7276.38	O.R. d. 72,76x1,78 Viton
11	N003.04	Paramotor head 2 lateral holes - black N003.04	Paramotor head 2 lateral holes - black
12	N012.87	Nut M8 knurled heads + washer 8x18 N012.87	Nut M8 knurled heads + washer 8x18
13	B9ES	Spark plug NGK B9ES B9ES	Spark plug NGK B9ES
14	99104.77	Spark plug boot 99104.77	Spark plug boot
15	N006.86	Standoff hex nut M8x44 N006.86	Standoff hex nut M8x44
16	57608.36	Exhaust gasket SKIPPER 57608.36	Exhaust gasket SKIPPER
17	99021.98	Prisoner drain M8x40 burnished 99021.98	Prisoner drain M8x40 burnished
18	N002.03	Cylinder gasket sets N002.03	Cylinder gasket sets

19	63103.76	Key for crankshaft flywheel side 63103.76	Key for crankshaft flywheel side
20	N001.26	Crankshaft bearing series+oil seals N001.26	Crankshaft bearing series+oil seals
21	N001.50	Crankcase engine man. starter w/o bracket N001.50	Crankcase engine man. starter w/o bracket
22	N001.42	Connector depressor /carb tube fitting N001.42	Connector depressor /carb tube fitting
23	N005.87	Bolt+washer for eccentric stop N005.87	Bolt+washer for eccentric stop
24	M9001.84	Drive bracket for engine slope 90° M9001.84	Drive bracket for engine slope 90°
25	VSTCE0615.86	Wheat bolt tensioner VSTCE0615.86	Wheat bolt tensioner
26	TCE0840ZN.86	Bolt TCE 08x40 zinc-coated TCE0840ZN.86	Bolt TCE 08x40 zinc-coated
27	N015.87	Bolt 8.8 6x25 ZN+Washer M6xD6,4 N015.87	Bolt 8.8 6x25 ZN+Washer M6xD6,4
28	N001.89	Special seger N001.89	Special seger
29	N002.26	Bearing series for secondary pulley N002.26	Bearing series for secondary pulley
30	N011.96	Bearing spacers series for pulley N011.96	Bearing spacers series for pulley
31	N013.87	Bolt+ washer x secondary pulley N013.87	Bolt+ washer x secondary pulley
32	M002.19	Primary pulley machined 15 groove d. 47/M M002.19	Primary pulley machined 15 groove d. 47/M
33	N022.87	Self locking nut + washer M12 N022.87	Self locking nut + washer M12
34	N001.09/15	Drive belt 15 ribs N001.09/15	Drive belt 15 ribs
35	N003.19	Secondary pulley d. 127 15 groves N003.19	Secondary pulley d. 127 15 groves
36	VSP10.90865ZN.86	TS screw propeller fixing 8x65 VSP10.90865ZN.86	TS screw propeller fixing 8x65
37	N002.40	Propeller plate N002.40	Propeller plate

38	N003.94	Wire throttle register N003.94	Wire throttle register
39	N001.47	Cable guide d. 12x5x19 N001.47	Cable guide d. 12x5x19
40	N001.00	Cylinder+complete piston+gaskets sets N001.00	Cylinder+complete piston+gaskets sets
41	N403008MFSG5.85	Motor mount Silent block 40x30 8MF N403008MFSG5.85	Motor mount Silent block 40x30 8MF
42	N014.87	Bolt+washer x crankcase fixing N014.87	Bolt+washer x crankcase fixing
43	M001.29	Ignition coil M001.29	Ignition coil
44	M024.87	Ignition coil bolts M024.87	Ignition coil bolts
45	M001.28	Flywheel manual ignition M001.28	Flywheel manual ignition
46	N003.86	Flywheel nut man. start 12x1,25 c/ron N003.86	Flywheel nut man. start 12x1,25 c/ron
47	M001.21	Bell manual starter M001.21	Bell manual starter
48	TCE0618ZN.86	Bolt TCE 06x18 zinc-coated TCE0618ZN.86	Bolt TCE 06x18 zinc-coated
49	M002.50	Flywheel cover plate M002.50	Flywheel cover plate
50	TB0510.86	Bolt TB 05x10 Flywheel cover bolt TB0510.86	Bolt TB 05x10 Flywheel cover bolt
51	N002.47	Ignition wire guide 18x72x9 N002.47	Ignition wire guide 18x72x9
52	M001.52	Complete manual pull starter M001.52	Complete manual pull starter
53	BR0816.86	Bolt key 8x16 rounded head BR0816.86	Bolt key 8x16 rounded head
54	M001.13	Spring manual starter with case M001.13	Spring manual starter with case
55	N001.03	Gasket set power plant N001.03	Gasket set power plant
56	N005.96	Aluminium spacer x manual version N005.96	Aluminium spacer x manual version

57	N003.96	Insulator spacer N003.96	Insulator spacer
58	57002.12C	Reed valve 57002.12C	Reed valve
59	N002.42	Aluminium flow-guide N002.42	Aluminium flow-guide
60	N004.96	Carburetor flange N004.96	Carburetor flange
61	TCE0630ZN.86	Bolt TCE 06x30 zinc-coated TCE0630ZN.86	Bolt TCE 06x30 zinc-coated
62	N019.87	Tube with 2 clamps N019.87	Tube with 2 clamps
63	N001.06	Carburetor Walbro 37-1 N001.06	Carburetor Walbro 37-1
64	N001.32	Airbox flange N001.32	Airbox flange
65	N020.87	Bolt 6x55 + washer M6 x D6,4 + split washer N020.87	Bolt 6x55 + washer M6 x D6,4 + split washer
66	N002.41	Metal clamp AIRBOX N002.41	Metal clamp AIRBOX
67	N001.05	Rubber sleeve –Airbox junction N001.05	Rubber sleeve –Airbox junction
68	N010.32	Airbox Minari engine complete N010.32	Airbox Minari engine complete
69	N004.32	Filter sponge inside airbox N004.32	Filter sponge inside airbox
70	N003.19C	Secondary pulley d.127 15 groves assembled N003.19C	Secondary pulley d.127 15 groves assembled
71	N024.87	Bolt + nut self-locking x airbox N024.87	Bolt + nut self-locking x airbox
72	N004.05 - N007.05	Joint exhaust attachment to the cylinder N004.05 - N007.05	Joint exhaust attachment to the cylinder
73	N001.45	Exhaust spring N001.45	Exhaust spring
74	N003.05 - N008.05	Exhaust's joint N003.05 - N008.05	Exhaust's joint
75	N002.08 - N015.08	Exhaust body expansion part N002.08 - N015.08	Exhaust body expansion part

76	N002.07	Aluminium exhaust silencer N002.07	Aluminium exhaust silencer
77	N018.87	Series 1 shaped bands inox + 1 rubber band N018.87	Series 1 shaped bands inox + 1 rubber band
78	N023.87	Bolt + washer fix band silencer N023.87	Bolt + washer fix band silencer
79	N001.08 - N016.08	Complete exhaust with aluminium silencer N001.08 - N016.08	Complete exhaust with aluminium silencer
80	N303008MF.85	Exhaust mount Silent block 30x30 N303008MF.85	Exhaust mount Silent block 30x30
81	TCE8.80830ZN.86	Bolt TCE 08x30 8.8 zinc-coated TCE8.80830ZN.86	Bolt TCE 08x30 8.8 zinc-coated
82	N001.82	Eccentric stretcher /tensioner N001.82	Eccentric stretcher /tensioner
83	E003.41	Support x engine starter complete E003.41	Support x engine starter complete
84	E002.52	Engine starter E002.52	Engine starter
85	57008.99	Nut d. 12x1,25 for fly-wheel cone 19 57008.99	Nut d. 12x1,25 for fly-wheel cone 19
86	E001.50	Crankcase for electric starter / no bracket E001.50	Crankcase for electric starter / no bracket
87	N004.83	Starter ring gear N004.83	Starter ring gear
88	N017.87	Br 6x18 zn + Ro 6,4x1,2x1,6 + D auto M6 N017.87	Br 6x18 zn + Ro 6,4x1,2x1,6 + D auto M6
89	N001.29	Ignition Coil cable 80mm N001.29	Ignition Coil cable 80mm
90	RF027.96	Head casing - Forced cooling RF027.96	Head casing - Forced cooling
91	N001.27	Engine cooling fan F1-RF N001.27	Engine cooling fan F1-RF
92	TBE0808ZN.86	Bolt TBE 109 08x08 zinc-coated TBE0808ZN.86	Bolt TBE 109 08x08 zinc-coated
93	N002.27	Air conveyor N002.27	Air conveyor
94	TB0515BR.86	Bolt TB 05x15 bronzed TB0515BR.86	Bolt TB 05x15 bronzed

95	TB0820ZN.86	Bolt TB 08x20 zinc-coated TB0820ZN.86	Bolt TB 08x20 zinc-coated
96	E001.75	Cylinder cup F1-AFE 45° E001.75	Cylinder cup F1-AFE 45°
97	N001.75	Cylinder cup F1-VRFE N001.75	Cylinder cup F1-VRFE
98	N002.96	Transducer mount N002.96	Transducer mount
99	MEC001.50	Crankcase for engine man+electric/no bracket MEC001.50	Crankcase for engine man+electric/no bracket
100	M001.22	Complete ignition for M-ME manual starter M001.22	Complete ignition for M-ME manual starter
101	MEC003.21	Starter bell manual/electric with charger MEC003.21	Starter bell manual/electric with charger
102	AE001.84	Transmission bracket mod. F1-AE AE001.84	Transmission bracket mod. F1-AE
103	MEC027.86	Wrought nut x fly-wheel man+electric+charger MEC027.86	Wrought nut x fly-wheel man+electric+charger
104	E9001.84	Transmission bracket mod. F1-E9 electric E9001.84	Transmission bracket mod. F1-E9 electric
105	N026.46	Complete fly-wheel ignition 19 / no coil N026.46	Complete fly-wheel ignition 19 / no coil
106	MAM45001.84	Transmission bracket / slope 45° MAM45001.84	Transmission bracket / slope 45°
107	MRV001.84	Transmission bracket vertical / reversed MRV001.84	Transmission bracket vertical / reversed
108	VERE001.84	Transmission bracket for VE-RE VERE001.84	Transmission bracket for VE-RE
109	RFV001.84	Transmission bracket for VRF RFV001.84	Transmission bracket for VRF
110	MEC026.46	Complete ignition MEC / no coil MEC026.46	Complete ignition MEC / no coil
111	E002.19	Primary pulley wrought 15 groves d. 47 elect E002.19	Primary pulley wrought 15 groves d. 47 elect
112	57002.28	Flywheel cone 19 57002.28	Flywheel cone 19
113	N002.94	Manual starter grip N002.94	Manual starter grip

114	E003.52	Engine starter for F1VR-FE E003.52	Engine starter for F1VR-FE
115	N001.40	Stator-holder plate N001.40	Stator-holder plate
116	MEC57002.28	Flywheel cone 19 Kg. 0,8 for MEC MEC57002.28	Flywheel cone 19 Kg. 0,8 for MEC
117	MEC028.98	Screw M8x10 ZNT TBEI 109 lav x starting bell MEC028.98	Screw M8x10 ZNT TBEI 109 lav x starting bell
118	V001.14	Crankshaft x F1-VRFE V001.14	Crankshaft x F1-VRFE
119	57001.3	Regulator (AC DC) 57001.3	Regulator (AC DC)
120	N001.04	Cylinder head d.66 F1-RF N001.04	Cylinder head d.66 F1-RF
121	NRELE001.22	Relay NRELE001.22	Relay
122	N003.14	Crankshaft for 200cc eng. Standard unit + clutch unit N003.14	Crankshaft for 200cc eng. Standard unit + clutch unit
123	N014.32	Airbox for 200 cc engines N014.32	Airbox for 200 cc engines
124	N009.50	Crankcase 200 cc engines with manual starter N009.50	Crankcase 200 cc engines with manual starter
125	N002.00	Cylinder + piston + gasket 200 cc engines N002.00	Cylinder + piston + gasket 200 cc engines
126	N005.04	Paramotor head for 200 cc engines N005.04	Paramotor head for 200 cc engines
127	N020.50	Crankcase for 200 engines electric starter ME9-CL-F N020.50	Crankcase for 200 engines electric starter ME9-CL-F
128	N004.04	Paramotor head for 2 spark plugs engines N004.04	Paramotor head for 2 spark plugs engines
129	N002-2C.96	Coil holder for 2 spark plugs engines N002-2C.96	Coil holder for 2 spark plugs engines
130	N002.96	Coil Holder N002.96	Coil Holder
131	N002.29	Ignition coil for 2 spark, plugs engines N002.29	Ignition coil for 2 spark, plugs engines
132	N004.22	Control Unit for 2 spark plugs engines N004.22	Control Unit for 2 spark plugs engines

133	N004.50	Crankcase for clutched engine (Manual starter) N004.50	Crankcase for clutched engine (Manual starter)
134	N003.19CFM	Secondary Pulley Assembled for clutch unit (Manual) N003.19CFM	Secondary Pulley Assembled for clutch unit (Manual)
135	N002.82	Eccentric Tensioner -Clutch unit (Manual starter) N002.82	Eccentric Tensioner -Clutch unit (Manual starter)
136	N010.08	Complete exhaust Black painted N010.08	Complete exhaust Black painted
137	N004.08	Exhaust body -Black painted N004.08	Exhaust body -Black painted
138	N006.05	Exhaust joint -Black painted N006.05	Exhaust joint -Black painted
139	N005.05	Joint from exhaust to cylinder-Black painted N005.05	Joint from exhaust to cylinder-Black painted
140	N006.14	Crankshaft + roller cage-Clutched engine (Manual) N006.14	Crankshaft + roller cage-Clutched engine (Manual)
141	M003.21	Clutch starter bell M003.21	Clutch starter bell
142	M003.50	Flywheel cover plate -clutched engines M003.50	Flywheel cover plate -clutched engines
143	N004.14	Crankshaft +roller cage-Clutched engine (Electric) N004.14	Crankshaft +roller cage-Clutched engine (Electric)
144	N019.50	Crankcase for clutched engine (Electric starter) N019.50	Crankcase for clutched engine (Electric starter)
145	N003.82	Eccentric tensioner-Clutch unit (Electric starter) N003.82	Eccentric tensioner-Clutch unit (Electric starter)
146	N003.19CFE	Secondary pulley assembled-Clutch unit (E-start.) N003.19CFE	Secondary pulley assembled-Clutch unit (E-start.)
147	N015.96	Engine starter spacer -Clutch units N015.96	Engine starter spacer -Clutch units
148	N005.14	Crankshaft+roller cage-Clutch unit 200cc (Manual st.) N005.14	Crankshaft+roller cage-Clutch unit 200cc (Manual st.)
149	N007.14	Crankshaft+roller cage-Clutch unit 200cc (Electric st.) N007.14	Crankshaft+roller cage-Clutch unit 200cc (Electric st.)
150	N010.50	Crankcase for engine F1-ME9-F (Clutched) N010.50	Crankcase for engine F1-ME9-F (Clutched)
151	N021.50	Crankcase for engine F1-E9-CL-F (200cc Clutched) N021.50	Crankcase for engine F1-E9-CL-F (200cc Clutched)

152	M004.52 TILL 2017	Easy starter with cover (Pull start for clutch engines) M004.52 TILL 2017	Easy starter with cover (Pull start for clutch engines)
153	M005.52 TILL 2021	Easy starter with plate (Pull start for clutch engines) M005.52 TILL 2021	Easy starter with plate (Pull start for clutch engines)